

DATA DOG


ARMED POLICE

© EIGHTING / RAIZING 1998

OPERATOR'S MANUAL

■ SETTINGS

- ☐ EDGE CONNECTOR
- ☐ JAMMA STANDARD
- ☐ VERTICAL SCREEN
- ☐ CONTROL PANEL



8WAY JOYSTICK



SHOT



BOMBER

※Maximum credits-9.

JAMMA

SOLDER SIDE			PARTS SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
N.C.	E	5	N.C.
+12V	F	6	+12V
	H	7	
COIN COUNTER 2 (COIN LOCK OUT 2)	J	8	COIN COUNTER 1 (COIN LOCK OUT 1)
SP(-)	K	9	SP(+)
N.C.	L	10	N.C.
N.C.	M	11	N.C.
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
N.C.	S	15	
COIN SW 2	T	16	COIN SW 1
START SW 2	U	17	START SW 1
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P PUSH 1	Z	22	1P PUSH 1
2P PUSH 2	a	23	1P PUSH 2
2P PUSH 3	b	24	1P PUSH 3
N.C.	c	25	N.C.
N.C.	d	26	N.C.
GND	e	27	GND
GND	f	28	GND

BATRIDER DIP-SW

[illegible][illegible]

DIP-SW3		1	2	3	4	5	6	7	8
SCREEN FLIP	OFF	OFF							
	ON	ON							
DEMO SOUND	ON		OFF						
	NO SOUND		ON						
STAGE EDIT	DISABLE			OFF					
	ENABLE			ON					
CONTINUE PLAY	ENABLE				OFF				
	DISABLE				ON				
INVINCIBLE	OFF					OFF			
	ON					ON			
NO USE							OFF	OFF	OFF
OEFAULT SETTING		OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF